0 0						0 0
0	PP-BS		EV-2A EV-2B EV-2C EV-2D			0
0 0						
		0		。 Main Disconnect	Utility Metering	
		0		。 Main Disconnect	Customer Metering	
	0	0		。 Main Disconnect	Utility Metering	
0 0	- 1			-		
0	SPARE		EV-1A EV-1B EV-1C EV-1D			0



LAYOUT